

Welcome to ALOGIC

Willkommen bei ALOGIC

Benvenuti a ALOGIC

Bienvenue à ALOGIC

Bienvenido a ALOGIC

ALOGICへようこそ

ALOGIC 에 오신것을 환영합니다

Quick Start Guide

Quick Start Guide



Introduction

The ALOGIC USB-C to USB-A and Power Splitter lets you use the latest ALOGIC USB-C DisplayLink Power dock with Power Delivery with a laptop with USB-A connection and a legacy barrel type (DC Jacks) or onelink power connection.

The splitter has been designed for a small footprint for minimal use of desk space. Integrated security loop allows for the splitter to be anchored securely to any desk with a lock.

It comes included with all the popular legacy laptop charging DC jacks for universal compatibility with all popular laptop brads as per the below list:

TIP	Notebook
A	Most Notebook
C	Dell
G	Acer
H	HP
M	Dell
I	HP
O	Asus
D1	Lenovo

Specifications


Model	DCAP-SPL
Input	USB-C with Power
Output	Data: USB-A/USB 3.0 (20cm) Power: DC Jack (20cm)
Warranty	2 Years

Package Contents

- ALOGIC USB-C to USB-A and Power Splitter
- Set of Power tips
- User Manual

Physical Layout

- 1 Power tips
- 2 USB-C
- 3 USB-A
- 4 DC Jack



User Instructions

1. Connect a USB-C to USB-C cable to a ALOGIC DisplayLink dock with Power Delivery and the other end to the ALOGIC Power Splitter.
2. Proceed to connect the tethered USB-A to the available USB-A port on your laptop.
3. Select the appropriate notebook DC Jack and connect it to your Notebook power Jack port.
* Power Tip NB DC Jack Table information below.
4. Charging will commence once connected and the ALOGIC DisplayLink dock with Power Delivery is turned on.

TIP	Notebook
A	Most Notebook
C	Dell
G	Acer
H	HP
M	Dell
I	HP
O	Asus
D1	Lenovo